


**NOTE:**  
 1- INSTALL THE ROOT BARRIER DIRECTLY ON TOP OF WATERPROOFING MEMBRANE.

**Xeroflor** NORTH AMERICA

WWW.XEROFLORNORTHAMERICA.COM  
 TOLL FREE: 1-866-335-1151

**XF+MW SYSTEM**

Detail at Vegetation Free Zone



SCALE 1:2

©2020