

XF+TR SYSTEM

XF 504, MODULAR TRAY

XF 100 SERIES, ROOT BARRIER

ROOFING SYSTEM

XF 604,
EDGING RESTRAINT

PRECAST CONCRETE PAVER WITH
BUILT-IN PEDESTALS


NOTE:
1- INSTALL THE ROOT BARRIER DIRECTLY ON TOP OF WATERPROOFING MEMBRANE.

Xeroflor NORTH AMERICA

WWW.XEROFLORNORTHAMERICA.COM
TOLL FREE: 1-866-335-1151

XF+TR SYSTEM

Detail at Vegetation Free Zone



SCALE 1:2

©2020